
Job	Sequence
Bare wood → stain	P80 → P120 → P150
Bare wood → paint	P80 → P120 → P180
Strip and refinish	P60 → P100 → P150 → P180
Between coats	P240 or P320, lightly
Car paint → polish	P800 → P1500 → P2000 (wet)
Drywall compound	P120 → P220